



HL400 / HL400-F DISPENSER USER INSTRUCTION

1 WALL MOUNTING




2 REFILLING: REFILL OR PREFILLED


OPTION A:
REFILL





OPTION B:
PREFILLED



3 ASSEMBLY A




ASSEMBLY B



4 DISPENSING

HL400



HL400-F

